
Re-Usage of ALBILEX[®]-3000 Cans

- Use of yellow degassing cap -

In the course of drinking-water tank cleaning there are often some remainders of ready-to-use (two-component-cleaner: ALBILEX[®]-3000 and ALBILEX[®]-3000-A) cleaning solutions after completion of the cleaning process.

Common cleaning agents are characterized by the necessity to dispose these left over ready-to-use solutions as they lose the cleaning effect rapidly after being mixed to a ready-for-use solution. Apart from the negative cost effect there may occur some disposal problems as one has to dispose high-concentrate cleaning solutions.

These disadvantages do not happen with our two-component cleaning agent ALBILEX[®]-3000 and ALBILEX[®]-3000-A.

What you have to do:

You may use the mixed, ready-to-use cleaning solution for the next cleaning session even a couple of years later but have to make sure that you close the can with the yellow degassing cap and store it upright with the yellow degassing cap on top afterwards.

The reason is that ALBILEX[®]-3000-A (Activator) contains hydrogen peroxide, which will decompose after a certain while and can cause a blow-up of the can in worst case if you do not use the yellow cap.

Before starting the next cleaning session (even when cleaning the next day) add a new bottle of ALBILEX[®]-3000-A (Activator) to ensure sufficient cleaning effect.

In case of further questions please contact our technical assistance.